

GROUND CONTROL SYSTEMS®
Offset® Strut
Mounting Instructions

NOTE: These instructions are for the unistrut or similar u-rail installation which may be used in wood-studded walls, metal-studded walls, and partially grouted CMU walls.

Installation Notes:


Requires 3 Unistrut Rails (Or similar sets of u-rails) to reach desired length
 Requires dock mounting kit 81000-0030 per each dock (includes channel nuts)

Wood Studs: recommended 5/16" x 5" lag bolts to mount to wall, with washer (not included)

Metal Studs: recommended use of toggle nuts, with washer (not included)

Partially Grouted CMU: recommended use of wedge anchors, with washer (not included)

Recommended kickboards: 1" x 4" Qty. 2 (full length) using 1/4" x 3-1/2" flathead screw to mount



DETAIL C
SCALE 1 : 16

